

Foreword

Thanks for choosing GAC Motor!


We are sure that GAC Motor will bring you greater driving pleasure. In order to keep your vehicle in good condition for a long time, please be sure to go to the GAC Motor authorized shop for regular maintenance in accordance with "Regular maintenance schedule" in this manual, where quality services will be provided for you at a reasonable price, and the technical personnel who have received professional training from GAC Motor Co., Ltd. (hereinafter referred to as "GAC Motor") will perform the maintenance according to the specific operation specification.

This manual is a certificate for the warranty and maintenance of your vehicle. Please enter the user information carefully in this manual and keep the manual properly. You are requested to present this manual when you accept the vehicle maintenance or apply for the vehicle warranty in the GAC Motor authorized shop.

Best wishes for you: hope GAC Motor can bring you pleasant driving experience!

GAC Motor Co., Ltd.

This manual is a certificate for the warranty and maintenance of your vehicle. For the 3-R's (repair, replacement and refund) warranty items, the *Warranty Certificate of Household Automotive Products and the Instructions for Warranty of Household Automotive Products shall apply*; for other warranty items, this manual shall apply. To ensure that you are entitled to the warranty and maintenance services provided by GAC Motor, please assist the staff of the authorized shop to fill in the User Information columns of the Warranty Registration Form in this manual when picking up the vehicle. If you do not fill in the Warranty Registration Form and make the warranty registration, we have the right to refuse to provide warranty services for you.



Registration sheet: Warranty Registration Form
When picking up your vehicle, please fill in the User Information columns and hand over the registration form to the authorized shop delivering your vehicle for archiving and entry of the information in GAC Motor management system.

First maintenance copy: First Maintenance Certificate
It is the First Maintenance Certificate of your vehicle. Please be sure to check whether the First Maintenance Certificate is provided when picking up the vehicle; if not, the free first maintenance service and warranty services will be invalidated. In that case, please refuse to accept the vehicle.

Warranty copy: Warranty Certificate
It is the Warranty Certificate of your vehicle. Please be sure to check whether the Warranty Certificate is provided; if not, the warranty services will be invalidated. In that case, please refuse to accept the vehicle.

The copyright of this manual is reserved by GAC Motor Co., Ltd. The Company is responsible for the revision, interpretation and explanation of this manual. The information and technical data contained in this manual are valid upon approved printing. GAC Motor Co., Ltd. may suspend the use of certain information or technical data or change certain information or technical data without prior notice, and does not assume any obligation arising therefrom.

Table of Contents

1.	Vehicle handover	9
1.1	PDI	9
1.2	Vehicle handover.....	9
2.	Warranty instructions	10
2.1	Warranty instructions	10
2.2	Responsibilities of vehicle owner	12
2.3	Obligations of GAC Motor authorized shop	12
3.	Maintenance instructions	13
3.1	First maintenance agreement.....	13
3.2	Regular maintenance schedule.....	14
3.3	Supplementary maintenance under harsh driving conditions.....	17
3.4	Regular maintenance record	19
4.	Defect report	24
5.	Ownership change	29

Warranty Registration Form

User Information	Vehicle Information
Owner name: _____	Vehicle model: _____
Owner's attribute: _____ Profession: _____	VIN: _____
Tel.: _____	Engine serial number: _____
Address: _____	Transmission number: _____
_____	Body color: _____
Postcode: _____	Interior trim color: _____
_____	Key number: _____
Contact person: _____	License plate number: _____
Tel.: _____	License issuance date: (/ /)
Address: _____	_____
_____	_____
Postcode: _____	_____
_____	_____
Purchase date: (/ /)	_____
_____	_____
Signature of vehicle owner: _____	Name of authorized shop: _____
(/ /)	(Seal)
_____	(/ /)

Registration copy: the authorized shop will keep on file the completed copy and enter the information in GAC Motor management system



First Maintenance Certificate

User Information	Vehicle Information
Owner name: _____	Vehicle model: _____
Owner's attribute: _____ Profession: _____	VIN: _____
Tel.: _____	Engine serial number: _____
Address: _____	Transmission number: _____
_____	Body color: _____
Postcode: _____	Interior trim color: _____
Contact person: _____	Key number: _____
Tel.: _____	License plate number: _____
Address: _____	License issuance date: (/ /)
_____	Date of first maintenance: (/ /)
Postcode: _____	Mileage of first maintenance: _____ km
Purchase date: (/ /)	Name of authorized shop conducting first maintenance: _____ (Seal)
Signature of vehicle owner: _____	Name of authorized shop: (Seal)
(/ /)	(/ /) (/ /)

First maintenance copy: the authorized shop will send the completed copy back to GAC Motor after conducting the first maintenance



Warranty Certificate

User Information

Owner name: _____

Owner's attribute: _____ Profession: _____

Tel.: _____

Address: _____

Postcode: _____

Contact person: _____

Tel.: _____

Address: _____

Postcode: _____

Purchase date: (/ /)

Signature of vehicle owner: _____
(/ /)

Vehicle Information

Vehicle model: _____

VIN: _____

Engine serial number: _____

Transmission number: _____

Body color: _____

Interior trim color: _____

Key number: _____

License plate number: _____

License issuance date: (/ /)

Date of first maintenance: (/ /)

Mileage of first maintenance: _____ km

Name of authorized shop
conducting first maintenance: _____ Name of authorized shop:
(Seal) (Seal)

_____ (/ /) (/ /)



1. Vehicle handover

1.1 PDI

The vehicle indicated in the Warranty Certificate attached in this manual has been subjected to PDI in accordance with the provisions specified by GAC Motor Co., Ltd. Please ask for the PDI checklist from the authorized shop for specific inspection items.

Inspection date:

Inspector:

Seal of authorized shop

1.2 Vehicle handover

Before delivery, the GAC Motor authorized shop will inspect and clean the vehicle completely and submit the PDI checklist to you for your confirmation and signature.

If you are unsatisfied with the condition of the delivered vehicle, please inform the GAC Motor authorized shop and ask for re-adjustment.

Please be sure to check whether the First Maintenance Certificate and Warranty Certificate are provided when you accept the vehicle; if not, the free first maintenance service and warranty services will be invalidated.

Followings are to be handed over with vehicle (e.g.: <input checked="" type="checkbox"/> Yes <input checked="" type="checkbox"/> No)	
<input type="checkbox"/> <i>Owner's Manual</i> <input type="checkbox"/> <i>Warranty Manual</i> <input type="checkbox"/> <i>Driving Guide</i> <input type="checkbox"/> <i>Navigation Manual (Optional)</i>	<input type="checkbox"/> First key <input type="checkbox"/> Second key <input type="checkbox"/> Spare tire <input type="checkbox"/> Warning triangle <input type="checkbox"/> Reflective vest <input type="checkbox"/> Driver's tools (refer to the Owner's Manual) <input type="checkbox"/> Free First Maintenance Certificate <input type="checkbox"/> Completed PDI Checklist
It is hereby confirmed that I have checked the items listed above and accepted the purchased vehicle.	
Signature of vehicle owner/ authorized person:	
*Please pay attention to checking, if any, the operation instructions provided for your vehicle.	

2. Warranty instructions

2.1 Warranty instructions

Warranty object

Vehicles manufactured by GAC Motor Co., Ltd., and sold and serviced by the GAC Motor authorized shop.



If you do not fill in the warranty copy and make the warranty registration, we have the right to refuse to provide warranty services for you.

The warranty services are provided to the owner of a new vehicle (if the vehicle owner changes within the warranty period, the warranty is still valid).

Warranty period

The warranty period refers to the period or mileage calculated from the date the dealer issues the purchase invoice.

Basic warranty period of GA6: 60 months or 150,000km (whichever comes first).

Warranty coverage

The warranty liability of GAC Motor is to repair products, including:

1. Repair or replacement of parts being considered defective by GAC Motor.
2. Repair of paint on vehicle body being considered defective by GAC Motor.
3. Man-hour cost for the above repair

Warranty terms

1. When verifying the warranty items, the GAC Motor authorized shop will consider the following conditions that are outside the warranty coverage of the GAC Motor:
 - a) Use of a vehicle in a country or region other than that where the vehicle is sold.
 - b) Vehicle damage caused by the maintenance, repair and adjustment performed in places other than the GAC Motor authorized shop.
 - c) Vehicle defects caused by use of parts, lubricating grease and liquids other than genuine ones specified by GAC Motor.
 - d) Vehicle damage caused by negligence, improper handling and the driving methods other than those specified in the *Owner's Manual* or the operation outside the limit operating range (such as maximum load and seating capacity) of the vehicle.
 - e) Vehicle damage caused by application of corrosive or low-quality cleaning agent.

- f) Modification, addition, adjustment and removal of the vehicle prohibited in the *Owner's Manual* without the approval of GAC Motor.
 - g) Vehicle damage caused by abnormal use, improper handling, negligence or the operation performed by the unqualified or unskilled driver and the application for races (such as vehicle race or motor rally).
 - h) Sensation problems that do not affect the vehicle performance.
 - The warranty of GAC Motor does not cover the defective sensation problems that do not affect the quality, function or performance of products.
 - i) Any damage caused by improper storage or transportation.
 - j) Vehicle defects caused by the natural disaster, fire, traffic accident, theft and the secondary damage incurred.
 - k) Vehicle damage caused by the environmental conditions other than the normal operation conditions of household automobiles (such as air pollution, chemical compound, guano, sea salt or other corrosive substances).
 - l) Vehicle corrosion or fault caused by the water immersion.
 - m) Vehicle surface corrosion caused by the flying stone or external scratch.
2. The warranty does not cover the maintenance items, fluids and auxiliary materials that are not necessary for the warranty and maintenance.
 3. The warranty does not cover the following incidental charges.

For example:

 - Expenses for communication, mediation, meal and accommodation because of a fault.
 - Any relevant personal injury or property damage.
 4. The GAC Motor reserves the right to determine the repair methods and warranty coverage.
 5. All parts under the warranty coverage are the property of GAC Motor.
 6. The fuel, lubricating grease and fluids specified by GAC Motor shall be used.



To avoid the dispute over the warranty liability, please note that:

- **The dispute over the warranty liability may arise if the vehicle is not subject to regular maintenance and inspection at a GAC Motor authorized shop according to the *Owner's Manual* and the *Warranty Manual*.**
- **The dispute over the warranty liability may arise if the user changes the original state of fault deliberately after the fault occurs so that the fault cannot be identified or the user has fraudulent behavior.**

2.2 Responsibilities of vehicle owner

1. Subject your vehicle to first maintenance at a GAC Motor authorized shop within 5,000km or 3 months (whichever comes first).
2. Make sure that your vehicle is maintained and inspected at the GAC Motor authorized shop according to the regular maintenance schedule in this manual.
3. Get any fault of your vehicle inspected and repaired at the GAC Motor authorized shop in time, which may be covered under the warranty.

CAUTION

- **The dispute over the warranty liability may arise if the vehicle is sent to any places other than the GAC Motor authorized shop for maintenance and repair.**
- **The vehicle that has not received first maintenance (referring to the maintenance within 5,000km or 3 months (whichever comes first)) will be rejected for free first maintenance.**

Please bring this manual with you when you go to the GAC Motor authorized shop.

2.3 Obligations of GAC Motor authorized shop

Fill in the Warranty Certificate contained in this manual and explain the warranty procedures of GAC Trumpchi vehicle when delivering a new vehicle to the user.

Explain the importance of regular maintenance fully to the user.

Ensure that any maintenance and repair can be completed according to the standard specified by GAC Motor, whether they are covered under the warranty or not.

For the damage or defects under the warranty coverage, the authorized shop should provide necessary vehicle repair or treatment to the user.

3. Maintenance instructions

3.1 First maintenance agreement

The first maintenance shall be completed within 5,000km or 3 months (whichever comes first).

The first maintenance is provided by GAC Motor free of charge. Please bring this manual to the GAC Motor authorized shop for first maintenance. The first maintenance includes:

1. Changing the engine oil, and replacing the drain bolt washer and oil filter
2. Adding the cleaning agent of fuel system (GDI)
3. Checking and adding:
 - a. transmission fluid
 - b. coolant
 - c. brake fluid
 - d. windshield washer fluid
4. Checking:
 - a. battery charging condition
 - b. operation of parking brake and brake pedal
 - c. dust cover of transmission drive shaft for leakage or damage
- d. tightening condition of wheel fixing bolt
- e. wear pattern and pressure of the tire/ hub (including the spare tire) (replace it when necessary)
- f. whether the connection of steering tie rod is firm
- g. condition of the underbody
- h. condition of suspension ball joint and dust cover
- i. condition of suspension assembly
- j. operation of wiper/washer (adjust the nozzle when necessary)
- k. operation of door check/ dowel pin, door lock, engine hood/ trunk lid hinge and latch
- l. operation of interior and exterior lamps and electrical consumers of the vehicle body
- m. thickness and wear pattern of the brake disc and brake lining
- n. operation of headlamp
5. Cleaning:
 - a. A/C filter element
 - b. air cleaner element
 - c. drain hole of the front windshield drip channel
6. Self-diagnosis:
 - a. Read OBD in-use monitoring data
 - b. Check the fault message with the professional diagnostic equipment

3.2 Regular maintenance schedule

If necessary, perform the maintenance according to the procedures for refilling, cleaning, adjustment, lubrication, repair or replacement after the inspection.

Perform the maintenance according to the specified mileage or time interval (whichever comes first)	Kilometer x 1000	20	40	60	80	100	120	140	160	180	200
	Months	12	24	36	48	60	72	84	96	108	120
★ Change the engine oil	First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months										
Replace the engine oil filter	First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months										
Replace the spark plug ^{*1}	Every 60,000km										
Check the accessory belt	Every 20,000km or 12 months										
Replace the accessory belt	Every 60,000km or 36 months										
Replace the fuel filter ^{*2}	Every 40,000km										
Replace the canister filter	Every 60,000km or 36 months										
Add the fuel system cleaning agent	First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months (GDI)										
Check and clean the air cleaner element	First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months										
Clean the air cleaner cover and replace the air cleaner element	Every 10,000km or 6 months										
★ Change the engine coolant	Every 40,000km or 24 months										
Check the transmission fluid	First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months										
Change the ATF	First at 60,000km, and thereafter every 40,000km										
Check the exhaust (only for leakage; the exhaust compositions are to be inspected during the annual inspection)	Every 10,000km or 6 months										
★ Change the brake fluid	Every 40,000km or 24 months										

Perform the maintenance according to the specified mileage or time interval (whichever comes first)	Kilometer x 1000	20	40	60	80	100	120	140	160	180	200
	Months	12	24	36	48	60	72	84	96	108	120
Check the parking brake and the brake pedal (check the function and free travel of the pedal and parking brake)	First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months										
Check the brake disc and brake lining (check their thickness and wear pattern, and replace them when necessary)	First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months										
Inspect the wheel fixing bolt (check and tighten the bolt to the specified torque)	First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months										
Check the wear pattern of the tire/ hub (including the spare tire), carry out tire rotation and correct the tire pressure when necessary	First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months										
Check the chassis bolts (check and tighten the bolts to the specified torque)	•	•	•	•	•	•	•	•	•	•	•
Check the brake system (check the brake fluid pipes for leakage and check the brake fluid level and add the brake fluid when necessary)	First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months										
Check the steering tie rod (check the clearance and check whether the connection is firm)	•	•	•	•	•	•	•	•	•	•	•
Check the underbody (check the fuel pipe, brake fluid pipe and underbody protective layer for damage, and the exhaust pipe for leakage and looseness)	First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months										
Replace the fuel hose	Every 96 months (or when any crack is found)										
Check the suspension ball joint and dust cover (check for loose ball joint or leaky dust cover)	•	•	•	•	•	•	•	•	•	•	•
Check the suspension assembly (check that the bush is free from aging and breakage, the connecting bolt and nut are tightened to specified torque and the linkage is free from deformation and cracks)	•	•	•	•	•	•	•	•	•	•	•
Check the wiper/washer (add the washer fluid and check the function of wiper/washer, adjust the nozzle when necessary)	First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months										
Clean the drain hole of the front windshield drip channel	First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months										

3. Maintenance instructions



Perform the maintenance according to the specified mileage or time interval (whichever comes first)	Kilometer x 1000	20	40	60	80	100	120	140	160	180	200
	Months	12	24	36	48	60	72	84	96	108	120
Check the door check, dowel pin, door lock, engine hood/trunk lid hinge and latch (check their functions and clean the dust on the door check and lubricate the check)		First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months									
Check the interior and exterior lamps and electrical consumers of the vehicle body		First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months									
Read OBD in-use monitoring data		Synchronized with vehicle maintenance									
Self-diagnosis (check the fault message with the professional diagnostic scan tool)		First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months									
Check the battery (check the battery condition with the special tool, check whether the connection between the positive and negative poles of battery is firm, and check the battery voltage)		First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months									
Check the headlamp (check the lamplight and adjust it when necessary)		First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months									
Check the A/C filter element		First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months									
Replace the A/C filter element		•	•	•	•	•	•	•	•	•	•
Test run (performance inspection)		Each time maintenance is done									
Visually check the following items											
Dust cover of transmission drive shaft (check for leakage or damage)		First and second times at 5,000km or 3 months, and thereafter every 10,000 km or 6 months									

- ★ : Be sure to check the levels (of engine oil, coolant and brake fluid) before driving.
- ¹: If there is impurity in the gasoline used, the spark plug should be replaced frequently. If the engine idle speed is unstable, the spark plug should be replaced immediately.
- ²: If there is impurity in the gasoline used, please replace the fuel filter frequently. If it is found that the fuel filter is blocked by impurities, replace the fuel filter immediately.

3.3 Supplementary maintenance under harsh driving conditions

The maintenance cycle is determined based on the normal driving conditions, therefore the maintenance frequency for certain maintenance items should be increased or the maintenance cycle should be shortened if the vehicle is used in harsh conditions.

Harsh driving conditions include the followings:

1. The vehicle often runs for a short trip (not more than 8km).
2. The engine is kept running at an idle speed continuously and the vehicle runs intermittently (for example: the vehicle is used as a taxi).
3. The vehicle runs in a muddy, dusty area or environment.
4. The vehicle is used to tow another vehicle frequently or to load the luggage on the roof rack during running, or the vehicle runs on a mountain road.
5. The vehicle runs for a long time in extreme cold (below 0°C) or hot (above 35°C) climates.
6. The vehicle runs more than 20,000 kilometers every year or runs at a high speed frequently.
7. The vehicle runs for a long distance at a low speed.

Item	Harsh conditions	Maintenance requirements
Change the engine oil and replace the oil filter	1, 2, 3, 5, 7	2,500km or 3 months
Change the engine coolant	3, 5, 6	40,000km
Check the wheel fixing bolt	1, 2, 3, 4, 5, 6	5,000km or 3 months

3. Maintenance instructions



Check the chassis bolts (check and tighten the bolts to the specified torque)	1, 2, 3, 4, 5, 6	10,000km or 6 months
Check the steering tie rod (check the clearance and check whether the connection is firm)	1, 2, 3, 4, 5, 6	10,000km or 6 months
Check the suspension ball joint and dust cover (check for loose ball joint or leaky dust cover)	1, 2, 3, 4, 5, 6	10,000km or 6 months
Check the suspension assembly (check that the bush is free from aging and breakage, the connecting bolt and nut are tightened to specified torque and the linkage is free from deformation and cracks)	1, 2, 3, 4, 5, 6	10,000km or 6 months
Replace the A/C filter element	3, 5	10,000km

Note:

The maintenance frequency of air cleaner and accessory belt shall be increased when the vehicle is used under harsh conditions.

3.4 Regular maintenance record

5,000 km or 3 months

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

10,000 km or 9 months

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

15,000 km or 15 months

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

20,000 km or 21 months

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

25,000 km or 27 months

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

30,000 km or 33 months

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

35,000 km or 39 months

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

40,000 km or 45 months

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

45,000 km or 51 months

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

50,000 km or 57 months

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

55,000 km or 63 months

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

60,000 km or 69 months

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

3. Maintenance instructions



65,000km or 75 months
Mileage: _____
Date: ____ (DD/MM/YYYY)
Authorized shop: _____
(Seal)

70,000km or 81 months
Mileage: _____
Date: ____ (DD/MM/YYYY)
Authorized shop: _____
(Seal)

75,000km or 87 months
Mileage: _____
Date: ____ (DD/MM/YYYY)
Authorized shop: _____
(Seal)

80,000km or 93 months
Mileage: _____
Date: ____ (DD/MM/YYYY)
Authorized shop: _____
(Seal)

85,000km or 99 months
Mileage: _____
Date: ____ (DD/MM/YYYY)
Authorized shop: _____
(Seal)

90,000km or 105 months
Mileage: _____
Date: ____ (DD/MM/YYYY)
Authorized shop: _____
(Seal)

95,000km or 111 months
Mileage: _____
Date: ____ (DD/MM/YYYY)
Authorized shop: _____
(Seal)

100,000km or 117 months
Mileage: _____
Date: ____ (DD/MM/YYYY)
Authorized shop: _____
(Seal)

105,000km
Mileage: _____
Date: ____ (DD/MM/YYYY)
Authorized shop: _____
(Seal)

110,000km
Mileage: _____
Date: ____ (DD/MM/YYYY)
Authorized shop: _____
(Seal)

115,000km
Mileage: _____
Date: ____ (DD/MM/YYYY)
Authorized shop: _____
(Seal)

120,000km
Mileage: _____
Date: ____ (DD/MM/YYYY)
Authorized shop: _____
(Seal)

125,000km

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

130,000km

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

135,000km

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

140,000km

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

145,000km

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

150,000km

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

155,000km

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

160,000km

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

165,000km

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

170,000km

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

175,000km

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

180,000km

Mileage: _____

Date: ____ (DD/MM/YYYY)

Authorized shop: _____

(Seal)

According to the relevant provisions in the *Regulation on the Administration of Recall of Defective Auto Products*, vehicle owners have the right to complain or reflect the defects of automotive products to the competent departments and relevant dealers. For this purpose, the GAC Motor has set a special window to accept your feedback, and if you find any defects in your GAC Trumpchi vehicle, please fill in the attached form and report it to the related competent department of GAC Motor.

GAC Motor acceptance window:

Tel: +86-400-158-9999

E-Mail: gacservice@gacmotor.com

Address: No. 633, East Road of Jinshan Avenue, Panyu District, Guangzhou, China

GAC Motor Co., Ltd.



4. Defect report

Owner's Report on Automobile Product Defects (Valid if copied)

A. Owner profile

Name (Enterprise name)			
ID number		Contact person*	
Address			
Postcode		E-mail	
Tel		Fax	

*: If the owner is a natural person, fill in the ID number or passport number in the ID number column; if the owner is an enterprise or public institution, fill in the entity code or legal person code of the enterprise and public institution.

B. Vehicle information

Brand			
Type			
Design		Model	
Engine number		Frame number	
VIN			
Vehicle category		Body type*	
Production date		Purchase date	
Mileage*		Is the vehicle a second-hand one	A. Yes B. No
Engine displacement		Number of cylinders	
Drive mode*		Whether ABS is installed	A. Yes B. No
Seat belt type*		Airbag type*	

: the items can be left blank.

Body type refers to: coupe, sedan, station wagon, truck and van.

Drive mode refers to: front-wheel drive, rear-wheel drive and four-wheel drive.



4. Defect report



C. Authorized shop information

Enterprise name			
Address			
Postcode		E-mail	
Tel		Fax	

D. Defect description

Defective system (such as brake system and steering system) and related descriptions:

E. Status when the defect is found

Time:

Mileage:

Vehicle speed:

Others:

F. Whether the manufacturer or the competent department responsible for the management of vehicle recall in China is involved:

A. Yes

B. No

G. Description of traffic accident

Does collision and fire occur: _____

Which airbag deploys: _____

Fatalities: _____

Estimated direct economic loss: _____

Others: _____

H. Description of tire problem (if any)

Owner (seal)

(/ /)



5. Ownership change

Ownership Change Record	
User Information	Vehicle Information
Owner name:	Vehicle model:
Owner's attribute: Male/female/unit Profession:	VIN:
Area: District, City (County), Province	Engine serial number:
Address:	Transmission number:
Postcode:	Body color:
Tel.:	Interior trim color:
Contact person:	Key number:
Address:	When the original registration content in the Warranty Certificate changes, the GAC Motor authorized shop must fill in the change record and report it to the GAC Motor.
Postcode:	
Tel.:	
Date of change: (/ /)	
<input type="checkbox"/> Owner change <input type="checkbox"/> Address change <input type="checkbox"/> Reissue	Name of authorized shop (seal):
Signature of owner:	Person in charge (signature):
(/ /)	(/ /)